

# Bamboo X Banner Stand - Installation Guide

Visible Graphic: 80cm x 180cm

Total Graphic Print Size: 80cm x 180cm

Requires: 9mm grommets in each corner (2cm from the banner's edge)

Material: Polypropylene Banner Media, PVC or Canvas

## Product Parts

- 1 - Bag
- 2 - Bottom Legs w/ Bamboo Fixture
- 3 - Top Legs (x2)
- 4 - Support Leg w/ Screw



## Step 1

Take all parts out of the bag and place on a clean flat surface

## Step 2

Remove the screw from support leg (4). Insert it into the Bamboo Fixture (2) and re-attach the screw. Make sure that the nut is facing away from the screw.




## Step 3

Spread the bottom Legs (2) and lay the assembled unit face up on the floor.



## Step 4


Slip each Top Leg (3) into the holes on the top of the Bamboo Fixture (2), being sure that the hooks face the same direction as those on the Bottom Legs (2)



## Step 5

Lay the banner flat, printed side up, on top of the banner stand. Slip the grommets into the hooks on each corner.

The Stand will need to bend, which will pull the banner taut. Stand the banner upright.



## Step 6

If necessary, the adjustment screw at the back of the fixture (2) allows the angle of the banner to be fine-tuned.

**Note-** When properly installed, the Support Arms (3) will bend pulling the banner taut. Installation of a banner smaller than the recommended size may cause permanent failure of the Display.